

Stainless steel packing instructions

Please follow these instructions carefully.
Damaged trolleys cannot be returned.

First lay the 2 wheels flat in the box

Cover wheels with cardboard or foam.
In the corners 4 equal parts of foam,
The wheels are now fixed.

The shaft with the motors in it.
The tubes that protrude go up
and aside. At GT-R, insert the smallest tube
backwards.

Place the front wheel with the tube.

Support wheel will lie here and diagonally above it
the scorecard holder.

Piece of foam between the tube and the front
wheel tube

2x foam at the bottom to fix the shaft.

2 x long foam on the long side.

The foam should not rise above the box.

Cover the small wheel with thin foam.

Insert the battery and with a thin piece of foam
secure.

The push tube in. Umbrella holder above
the axis. Hinge section on the small wheels.

The box with battery charger between the
umbrella holder and the tube.

Foam between short side and handle.

piece of foam between long side and tube
to fix this.

Cover and glue on well.

Shipping sticker on it and sending.



GolfTed.nl